



For all iCombi Pro and iCombi Classic devices

Active Green cleaner tabs
N°: 56.01.535



Care tabs
N°: 56.00.562



For all SelfCookingCenter® with Care Control
(from september 2008)

Cleaner tabs
N°: 56.00.210



Care tabs
N°: 56.00.562



For all CombiMaster® Plus (since May 2017)
SelfCookingCenter® without CareControl (until August 2008)

Cleaner tabs
N°: 56.00.210



Rinse aid tabs
N°: 56.00.211



CombiMaster®, CombiMaster® Plus
(until May 2017 - without cleaning) and ClimaPlus Combi®

Special cleaner soft
N°: 9006.0136

Grill cleaner
N°: 9006.0153

Rinsing Chemical Descaler
N°: 9006.0137 N°: 6006.0110

